

ShutdownAgent 2012

User Manual

Doc. Version 00.02

Date: 07/06/2012

About this manual

This manual contains information on installation and operation of the ShutdownAgent 2012 software.

Save this Manual

This manual contains instructions and warnings that should be followed during the installation, operation and storage of this product. Failure to heed these instructions and warnings will void the product warranty.

Contents


1.	Overview	. 2
	1.1 Features	2
	1.2 OS Support	2
2.	Installation/ Uninstallation	. 4
	2.1 For Windows System	4
	2.1.1 Installation Process	
	2.1.2 Uninstallation Process	7
	2.2 For Linux System	
	2.2.1 Installation Process	
	2.2.2 Uninstallation Process	
3.	Console Configuration	10
	3.1 Console Menu	. 10
4.	Operation in Windows	12
	4.1 Web Monitor	. 12
	4.2 Property	. 12
	4.3 Show Countdown	. 15
	4.4 Cancel Countdown	. 15
	4.5 Stop Service	
5.	Web Interface	16
	5.1 Run a Web Browser	. 16
	5.2 Monitor >> Information >> Summary	. 17
	5.3 Monitor >> Information >> Event Log	. 18
	5.4 Monitor >> Information >> Log Configure	. 19
	5.5 Device >> Host >> Configure	. 20
	5.6 Device >> Host >> Control	
	5.7 Device >> Host >> Forward Trap	
	5.8 Device >> SNMP >> SNMP Access	
	5.9 Device >> SNMP >> SNMPv3 USM	
	5.10 System >> Administration >> Information	
	5.11 System >> Administration >> Login User	
	5.12 System >> Administration >> Web	
_	5.12 System >> Administration >> Batch Configuration	
	2008 Server Core Setup for ShutdownAgent	
7.	VMWare ESXi4 Setup for ShutdownAgent	
	7.1 Configure the Firewall for ESXi 4	
	7.2 Install VMware Tools for Guest OS	
	7.3 Configure ShutdownAgent for ESXi4	. 32
8.	VMWare ESXi5 Setup for ShutdownAgent	34
	8.1 Configure the Firewall for vMA	. 34
	8.2 Install VMware Tools for Guest OS	

ShutdownAgent 2012

8.3 Configure ShutdownAgent for ESXI5	35
8.4 Modify the Command.ESX5	36
9. XenServer Setup for ShutdownAgent	38
9.1 Install PV driver for Guest OS	38
9.2 Configure UPSentry Cloud for Xen	38
10. Linux KVM Setup for ShutdownAgent	
10.1 Install libvirt Tools for KVM	40
10.2 Configure ShutdownAgent for KVM	40
11. Work with the SNMP Card	42
11.1 Legacy Delta InsightPower SNMP Card	42
11.2 New Delta InsightPower SNMP IPv6 Card	44

1. Overview

The ShutdownAgent 2012 is a software that can protect the operating system which is supplied power by an UPS during input power fail. Through a Web Browser, you can easily obtain current UPS event, shutdown strategy and countdown to shutdown information.



1.1 Features

- 1. Support SNMPv1, v3 trap.
- 2. Support SNMPv1, v3 server access for monitoring ShutdownAgent status and configure shutdown parameters.
- 3. Provide web interface through HTTP and HTTPS.
- 4. Provide the batch configuration to deploy settings at a finger click.
- 5. Forward SNMP trap to extend protecting up to 255 servers.
- 6. Support up to 32 input trap sources for redundant (logical OR) and parallel (logical AND) application.
- 7. Provide console configuration for basic system parameters setup.
- 8. Support Windows 32/64 bits setup programs.

1.2 OS Support

Windows XP-sp2, Vista, 7

Windows 2003, 2008

Windows 2008 Server Core, Hyper-V 2008 R2

Linux OpenSUSE 11.4

ShutdownAgent 2012

Linux ubuntu 10.04 Linux Fedora 3.1.9 CentOS 5.8 VMWare ESXi 4.1, 5 Citrix XenServer 6.0.0

Linux KVM


2. Installation/ Uninstallation

2.1 For Windows System


There are 2 of setup programs: ShutdownAgent-2012-Setup(win32).exe and ShutdownAgent-2012-Setup(x64).exe. One is for 32 bit Windows operating system and the other one is designed for 64 bit Windows environment.

2.1.1 Installation Process


- 1. Execute the ShutdownAgent-2012-Setup(xxx).exe to run the setup program.
- 2. The welcome page will first display, press the "Next" button to continue the installation or press the "Cancel" to stop the installation.




3. Then continue to show the license agreement page. Press "Yes" button to continue the installation and "No" to stop the installation.




4. At this stage you can change the destination location by pressing the "Browse" button or just press the "Next" to install the software in the default path.




5. Now the setup program is ready for your confirmation to start copying the related program files. Press the "Install" button to start copying the software to the destination location in your hard drive.




6. Now the setup program is copying the files and shows the progress.



7. After complete the installation, press the "Finish" button to exit the installation process.



8. After finishing the installation, the ShutdownAgent will start the service program automatically and add an icon to indicate its status to the desktop tool bar. Meanwhile, a dialog box pops up to ask for launching the Agent-Config application to do the basic configuration. If you are not operate a Windows server core operating system then you can ignore this ask. Just press "No" to finish the installation. Press "Yes" to launch the Agent-Config in the shell mode. Please refer to the chapter 3 for the detail of Agent-Cofnfig.



The **ShutdownAgent** software is comprised of two modules:

A Service module (Shutdown-Agent Service: Agent-Service.exe), which runs in the background as a Service and listen for the SNMP trap from the source IP addresses.

A **Status** module (**Agent-Status.exe**), which enables you to control and configure the software through drop down menus and dialog boxes. It also allows you to launch the web browser and login automatically to monitor, configure and control the software.

After finishing the installation, the setup program will create a **SNMP ShutdownAgent** association with the following shortcuts:

Console Configure: To launch the Agent-Config.exe for you to quickly configure the basic communication parameters.

Uninstall: To remove the **SNMP ShutdownAgent 2012** from your hard disk, the configuration data will still be kept in the installed directory.

User Manual: The user manual in pdf format.


Web Monitor: The major user interface of **ShutdownAgent**, used to monitor and configure the software.

2.1.2 Uninstallation Process

- Select the Uninstall from the SNMP ShutdownAgent program folder to start the un-installation process. Or you can start the SNMP ShutdownAgent uninstallation process from the Add/Remove Program of the Control Panel.
- 2. Press the "OK" button to confirm removing all of the application from the hard drive or "Cancel" to cancel the un-installation process.




3. Press the "Finish" button to complete the un-installation process.



2.2 For Linux System

2.2.1 Installation Process

- 1. Please login to the Linux system and change to the root account: su root
- 2. Copy the sa2012-linux.tar.gz to the /tmp directory: cp sa2012-linux.tar.gz /tmp
- 3. Change your working directory to /tmp: cd /tmp
- 4. uncompress the sa2012-linux.tar.gz: gunzip sa2012-linux.tar.gz
- 5. extract the sa2012-linux.tar: tar xvf sa2012-linux.tar
- 6. Run the install script:
 - ./install



7. Press 'y' to proceed the installation process:

8. Now the ShutdownAgent has been installed in the following directory /usr/local/upsagent/ and the service program starts up automatically.

Press 'y' to launch the /usr/local/upsagent/configure program to configure the basic networking parameters for ShutdownAgent or press 'n' to finish the install process.

Please see chapter 3 for more information if you want to configure the basic networking parameters.

2.2.2 Uninstallation Process


- 1. Please login to the Linux system and change to the root account: su root
- 2. Change your working directory to /usr/local/upsagent: cd /usr/local/upsagent
- 3. Run the uninstall script to remove ShutdownAgent: ./uninstall
- 4. Press 'y' to start the uninstallation process.

3. Console Configuration

The configuration program is design to do the basic configuration for the ShutdownAgent in the shell mode. The software can be launched at the end of the installation process or you can go to the installed directory to launch it manually.

For Windows it locates in "C:\Program Files\SNMP Shutdown Agent 2012\Agent-Config.exe"

For Linux it is installed in "/usr/local/upsagent/configure"



3.1 Console Menu

No.	Function	Description	Default
1.	SNMP Trap Port	The UDP port to listen for the SNMP trap	162
2.	SNMP Server Port	The UDP port for replying get/set commands	161
3.	HTTP	Enable or disable the HTTP protocol	Enable
4.	HTTPS	Enable or disable the HTTPS protocol	Enable
5.	HTTP Port	The TCP port for HTTP	80
6.	HTTPS Port	The TCP port for HTTPS	443
7. Manageable		Allow the management software to manage ShutdownAgent	Enable
8. Save		Save the configured parameters to agent.ini	
9. Set Firewall		Insert or remove the firewall rule for the	

ShutdownAgent 2012

		ShutdownAgent. This option is provided for	
		quickly testing the network communication. The	
		firewall settings may be recovered after the OS	
		reboots.	
a.	Restart Shutdown-	Restart service program to apply the changes	
u.	Agent Service	incitate service program to apply the changes	
0.	Exit	Exit the configuration program	

4. Operation in Windows

After installation, the ShutdownAgent places an icon in the desktop toolbar to indicate the status of monitoring UPS.

Icon	Description
<u>©</u>	Normal
S	Service stop
••	UPS on battery mode
■ UPS battery low	
S	UPS on bypass mode

To show the pop up menu, please move the mouse cursor over the ShutdownAgent icon and click the mouse button to pop up the menu:



4.1 Web Monitor


ShutdownAgent implemented a web engine to provide the web interface to interact with the end customers. You can monitor and configure the software through the web interface.

Select the **Web Monitor** menu item from the menu to launch the default web browser, if your login account in the Windows system belongs to the local Administrators group then ShutdownAgent will login to its web engine automatically as the administrator privilege. If you connect a web browser from a remote PC then you have to key in the account and password by yourselves. For more detail information about the web operation, please refer to the chapter 5.

4.2 Property

Select the **Property** menu item will pop-up the Property dialog box which provides another quick way to configure the basic parameters of ShutdownAgent.

From the General page you can observe the software version number, IP addresses and host name.



Language:

Select the supported language from this option.

HTTP:

To enable/ disable the HTTP protocol, assign a different number of the Port number to change the HTTP connection through the other network port.

The default value is 80.

If you have changed the HTTP port number from 80 then you have to key in the connection URL as the following:

http://192.168.1.100:8001

where 192.168.1.100 is the ip address of the PC which ShutdownAgent installed and the 8001 is the port number which you assigned.

NOTE: Please check the Windows firewall setting if the HTTP connection is refused.

HTTPS:

To enable/ disable support the HTTPS protocol, assign a different number of the Port number to change the HTTPS connection through the other network port. The default value is 443.

If you have changed the HTTPS port number from 443 then you have to key in the connection URL as the following:

https://192.168.1.100:4430

where 192.168.1.100 is the ip address of the PC which ShutdownAgent installed and the 4430 is the port number which you assigned.

NOTE: Please check the Windows firewall setting if the HTTPS connection is refused.

Login Account:

The ShutdownAgent implements 3 levels of authentication for the web login as the following:

Administrator:

Has sole right to modify the ShutdownAgent system settings.

Device Manager:


Is not permitted to change the system settings but has the ability to configure the device settings.

Read Only User:

Can observe the connected devices only.

The following is the default account and password list, please note that they are case-sensitive.

	Account	Password
Administrator	admin	password
Device Manager	device	password
Read Only User	user	password



4.3 Show Countdown

Select the Show Countdown menu item to display the countdown windows when the ShutdownAgent start to counting down the OS shutdown delay.



4.4 Cancel Countdown

Select the Cancel Countdown menu item during the counting down to stop the shutdown process. To resume the shutdown process, please de-select the Cancel Countdown menu item to counting down the OS shutdown delay.

In addition to de-select the Cancel Countdown menu item to continue the countdown process, when the shutdown event changes the software will start a new countdown process.

4.5 Stop Service

Select the Stop Service menu item to stop the ShutdownAgent service module. To start the service again please de-select the Stop Service menu item.

5. Web Interface

5.1 Run a Web Browser

To connect a web browser from the same PC which ShutdownAgent installed, please select the **Web Monitor** from the toolbar menu, ShutdownAgent will open your default web browser and if your Windows account belongs to the local Administrators group then the ShutdownAgent will login as an administrator for you automatically.


ShutdownAgent allows at most 16 users login at the same time.

You can also connect a web browser from a remote PC, please follow the steps: Make sure that you have a **TCP/IP** network installed.

Start your Web Browser. Enter http://host_name or http://ip_address in the address bar for the plain text web transmission or https://host_name or https://ip_address for the encrypted web transmission. If you have changed the port number of HTTP or HTTPS then please enter http://host_name:port_number or http://ip_address:port_number in the address bar for the plain text web transmission or https://host_name:port_number or htt

//ip_address:port_number for the encrypted web transmission


The ShutdownAgent will then ask your account and password. After keying in the correct **account** and **password**, the **ShutdownAgent Home Page** will appear on the screen.



Note: The ShutdownAgent will logout the user automatically if there is no any data transmission through HTTP/HTTPS for more than 30 minutes.

5.2 Monitor >> Information >> Summary

This web page includes the information of identification, shutdown status, source IP status and the last 5 event logs.



Host:

Include the host name, the listen UDP port for SNMP trap and the description of operating system.

Shutdown:

Display the shutdown type (Shutdown, Power Off, Hibernate) and the countdown time to shutdown the OS in second.

SNMP Trap Source IP List:

ShutdownAgent is capable of receiving SNMP traps from multiple source hosts then decide to determine the event by logical OR for redundant application and logical AND for parallel application.

Last 5 Event Log:

Show the last 5 event logs, if you want to see more please visit the Event Log page.

5.3 Monitor >> Information >> Event Log

This web page lists all the events that have detected by the software. The existing logs are overwritten when the maximum number of entries (rows) has been reached. And the maximum number of event is 10,000. You can also download the software event log to a .csv format file.

Log Page Buttons:


Press the "<<" button to go to the newest page and the ">>" button to go to the oldest page. Click on the page number buttons to observe the event log by page.

Range of Date:

You can also filter the event log by assigning a period of date. Fill in the From and To text boxes then press the Apply button to request the event log by your assigned period of date.

Download All:

Press the **Download All** button to export all of the event log to a .csv format of file.



5.4 Monitor >> Information >> Log Configure

This page lets the Device Manager clear event log.

Clear Event Log:

To clear all of the data log by clicking this button.




5.5 Device >> Host >> Configure

This page is used to configure the major functions, they are: Shutdown, Reaction and Source IP.

Shutdown:

Select the **Shutdown Type** to determine the way to shutdown the operating system. There are **Shutdown**, **Power Off** and **Hibernate** types and the default value is Shutdown.

Now we should continue to determine the shutdown delay time for the following 4 power events: Power Fail, Battery Low, Overload and Smart Shutdown. If the power events recover during countdown then the operating system will not be shutdown.



Reaction:

Enable the **Notify Message** to pops up a message box once ShutdownAgent receives the SNMP traps from the source IP addresses. Assign the period value to report the message periodically, set a 0 to the Period will show the message only once. Enable the **Execute Command File** to run an assigned external file before shutdown. Set a value to the **Run Before Shutdown** to inform ShutdownAgent when to launch the assigned executable file.

Source IP:

Assign the **Receive Trap Port** to open the specific UDP port for receiving SNMP trap. Then select the Redundant(Logical OR) or Parallel(Logical AND) for the application purpose.

Redundant(Logical OR): Summarize the received power event by logical OR for all of the source IP addresses to determine whether the power event occurs or not. So if the power event occurs in one of the source IP addresses then the power event is tenable and the ShutdownAgent starts to countdown accordingly. Only when the power event recovers from all of the source IP addresses the ShutdowAgent stops countdown and cancel the shutdown process.

Parallel (Logical AND): Summarize the received power event by logical AND for all of the source IP addresses to determine whether the power event occurs or not. So if the power event occurs in all of the source IP addresses then the power event is tenable and the ShutdownAgent starts to countdown accordingly. Once the power event recovers from one of the source IP addresses the ShutdowAgent stops countdown and cancel the shutdown process.

Source IP Address: Assign the source IP address, ShutdownAgent will parse the SNMP trap only when the packet is received from the assigned IP addresses.


Community: If the value is not empty then only the received trap with the same community string will be accepted. If the value is empty then ShutdownAgent will accept any of the received community string.

SNMPv3 User: This field is used for SNMPv3 packet. If the value is not empty then only the received trap with the same user defined in the

SNMPv3 USM table will be accepted. If the value is empty then ShutdownAgent will accept the users which assigned in the SNMPv3 USM table.

Manageable:


Select the Allow the ShutdownAgent to be managed by an authenticated manager option to let the ShutdownAgent reply the query from any authenticated manager. The authenticated manager can be a SNMP card or a centralized management software. After collecting the ShutdownAgent information, the authenticated manager can provide a comprehensive list of all of the ShutdownAgent.



In fact, the authenticated manager communicate with the ShutdownAgent through SNMPv3 with the first default account in the SNMPv3 USM list. If the Allow the ShutdownAgent to be managed by an authenticated manager option is enabled then the permission of "manager" account changes to "Read/Write", otherwise the permission is "Disable".

The default setting of Allow the ShutdownAgent to be managed by an authenticated manager option is "enabled".

5.6 Device >> Host >> Control



Control:

Press the Cancel Countdown button during the countdown shutdown process to stop counting down. Press the button again to resume the shutdown process.

Forward Simulation Trap:

Press the Power Fail button to send the simulated power fail SNMP trap to the assigned forward target IP addresses.

Press the Power Restore button to send the simulated power restore SNMP trap to the assigned forward target IP addresses.

5.7 Device >> Host >> Forward Trap

Forward Trap is used to forward the received SNMP trap to extend the size of protection OS shutdown gracefully.



5.8 Device >> SNMP >> SNMP Access


The shutdownAgent supports SNMP protocol and SNMP NMS (Network Management System), which are commonly used to monitor network devices for conditions that call for administrative attention. To prevent unauthorized access, you can specify the NMS IP addresses that are allowed to access, their community strings and access levels. The maximum number of IP entries is 255.



5.9 Device >> SNMP >> SNMPv3 USM


SNMPv3 offers features such as the encryption of packets and authentication to improve security. The SNMPv3 USM (User Session Management) allows you to assign 32 User Names whose access is granted via SNMPv3 protocol. You can also define their respective Security Levels, Auth Passwords, Priv Passwords and Permission.

The first one account cannot be deleted, to disable it please go to the Device >> Host >> Configure web page then uncheck the manageable option.



5.10 System >> Administration >> Information

Here to assign the system information for the ShutdownAgent, including Installation Date, Location and Description.



5.11 System >> Administration >> Login User

You can manage the login authentication for web interface by assigning 3 different level of users' account and password.

The access permission for the account types are listed as follows:

Administrator: Permitted to modify all settings.

Device Manager: Permitted to modify device-related settings.

Read Only User: Only permitted to observe ShutdownAgent status.



5.12 System >> Administration >> Web

This menu lets the administrator enable or disable the HTTP/HTTPS communication protocols available in the ShutdownAgent.



HTTP:

Enabling or disabling the HTTP connection with the ShutdownAgent.

HTTPS:

Enabling or disabling the HTTPS connection with the ShutdownAgent.

HTTP Port:

The user may configure HTTP protocol to use a port number other than standard HTTP port (80).

HTTPS Port:

The user may configure HTTPS protocol to use a port number other than standard HTTPS port (443).

Web Refresh Period:

The period of time to update the monitoring web pages. The range is $1\sim9999$ seconds.

SSL Certificate:

To ensure connection security between the ShutdownAgent and the

connecting workstation, SSL certificate can be used to encrypt and secure the integrity of transmitting data.

Certificate File: This allows you to replace your own SSL certificate file. The ShutdownAgent supports PEM format which is generated by OpenSSL. Click **Choose File** to upload a certificate file.

5.12 System >> Administration >> Batch Configuration


The ShutdownAgent provides batch configuration to allow quick and effortless setup on multiple ShutdownAgent hosts. You can duplicate settings by downloading the configuration file from the ShutdownAgent that you have successfully configured, and upload the configuration files on other hosts.

Download:

Download the agent.ini for you to store or edit the configuration file.

Upload:

Upload the configuration file to ShutdownAgent to apply the change immediately.



6. 2008 Server Core Setup for ShutdownAgent

While installation the ShutdownAgent in the 2008 server core, it requires the following commands to transfer the file and add some rules for firewall.

1. Disable firewall:

netsh advfirewall set allprofiles state off

2. Enable firewall:

netsh advfirewall set allprofiles state on

3. Add a remotely shared directory:

net use e: \\<ip address>\e

4. Open the SNMP Trap UDP 162

netsh advfirewall firewall add rule name="SNMPTrap" protocol=UDP dir=in localport=162 action = allow

5. Open SNMP Server UDP 161

netsh advfirewall firewall add rule name="SNMPServer" protocol=UDP dir=in localport=161 action = allow

6. Open the HTTP TCP 80

netsh advfirewall firewall add rule name="HTTP" protocol=TCP dir=in localport=80 action = allow

7. Open HTTPS TCP 443

netsh advfirewall firewall add rule name="HTTPS" protocol=TCP dir=in localport=443 action = allow

Firstly, put the Shutdown-Agent-2012-Setup(x64).exe setup file in the 2008 server directory. If there is no CD-ROM you can set the "Disable firewall" command, "Add a remotely shared directory" command then copy the file from your PC to the 2008 server. Don't forget to set the "Enable firewall" command when complete.

Secondly, follow the chapter 2 to install the ShutdownAgent in the 2008 server. The last step is use the open HTTP/HTTPS, SNMP Trap/Server port commands to open the necessary which you want.

You can easily run the Agent-Config.exe to configure the basic networking parameters for the web and SNMP network protocols after installation.

```
- - X
C:\Program Files\SNMP Shutdown Agent 2012\Agent-Config.exe
     Shutdown Agent
[1].SNMP Trap Port:
[2].SNMP Server Port: 161
[3].HTTP:
                       Enable
[4].HTTPS:
                       Enable
[5].HTTP Port:
[6].HTTPS Port:
                       443
[7].Save
[8].Set Firewall
[9].Restart Shutdown-Agent Service
[0].Exit
Please Enter Your Choice =>
```

Select [8] to help you to insert or remove a firewall rule for the ShutdownAgent.

```
C:\Program Files\SNMP Shutdown Agent 2012\Agent-Config.exe
       Shutdown Agent
[1].SNMP Trap Port:
[2].SNMP Server Port: 161
[3].HTTP:
                            Enable
[4].HTTPS:
                            Enable
[5].HTTP Port:
                            80
[6].HTTPS Port:
                            443
[7].Save
[8].Set Firewall
[9].Restart Shutdown-Agent Service
[0].Exit
Please Enter Your Choice => 8
We'll help to insert or remove the firewall rules of ShutdownAgent for you,
you'll need to save and restore the firewall rules by yourselves if it works.

Do you want to insert or remove the firewall? [I]nsert, [R]emove

Please Enter Your Choice => _
```

7. VMWare ESXi4 Setup for ShutdownAgent

Before installing the ShutdownAgent in the ESXi4 server, please transmit the ShutdownAgent setup file to the ESX server through SFTP by FileZilla FTP Client or other SFTP client then login to the ESX server by the local console or through your favorite SSH client (such as Putty).

Please continue to follow the section 2.2 For Linux Installation/ Uninstallation.

To configure the basic networking parameters including the ESXi4 firewall, please see chapter 3 Console Configuration.

7.1 Configure the Firewall for ESXi 4

Run the /usr/local/upsagent/configure

Select [8] to help you to insert or remove a firewall rule for the ShutdownAgent.

```
C:\Program Files\SNMP Shutdown Agent 2012\Agent-Config.exe
     Shutdown Agent
[1].SNMP Trap Port:
[2].SNMP Server Port:
                      161
[3].HTTP:
                       Enable
[4].HTTPS:
                       Enable
[5].HTTP Port:
[6].HTTPS Port:
                       443
[7].Save
[8].Set Firewall
[9].Restart Shutdown-Agent Service
Please Enter Your Choice => 8
We'll help to insert or remove the firewall rules of ShutdownAgent for you,
you'll need to save and restore the firewall rules by yourselves if it works.
Do you want to insert or remove the firewall? [I]nsert, [R]emove
Please Enter Your Choice =>
```

7.2 Install VMware Tools for Guest OS

To shutdown the guest OS from ESXi server, it's better for you to install the VMware tools for all of them so as to inform the guest OSes shutdown smoothly.

For Windows operating system.


Select the following menu Guest → Install/Upgrade VMware Tools

7.3 Configure ShutdownAgent for ESXi4


The only thing that you need to do is to estimate the period of time during shutdown all of the guest operating systems which run in the ESXi4 server.

Then


- 1. Login to the web interface of ShutdownAgent and the account level should greater than or equal to device manager.
- 2. Goto the Device → Host → Configure web page and fill the estimated time in the Run Before Shutdown field of the Reaction group.



3. We have built the **command.ESX4** script file for ESXi 4 to shutdown the guest OSes, please change the file name in the Execute Command File field to the command.ESX4 then check the Execute Command File checkbox to enable shutdown the guest OSes.



4. Press Submit button to update your changes.




8. VMWare ESXi5 Setup for ShutdownAgent

Before installing the ShutdownAgent for the ESXi5, you have to install the vMA 5(vSphere Management Assistant 5) and make sure the VMWare tools is installed in all of the guest OSes. Please then transmit the ShutdownAgent setup file to the vMA server through SFTP by FileZilla FTP Client or other SFTP client then login to the vMA server by the local console or through your favorite SSH client (such as Putty).

Please continue to follow the section 2.2 For Linux Installation/ Uninstallation.

To configure the basic networking parameters including the vMA firewall, please see chapter 3 Console Configuration.



8.1 Configure the Firewall for vMA

Run the /usr/local/upsagent/configure

Select [8] to help you to insert or remove a firewall rule for the

ShutdownAgent.

```
- 0 X
C:\Program Files\SNMP Shutdown Agent 2012\Agent-Config.exe
      Shutdown Agent
[1].SNMP Trap Port:
[2].SNMP Server Port: 161
[3].HTTP:
                         Enable
[4].HTTPS:
                         Enable
[5].HTTP Port:
[6].HTTPS Port:
                         443
[7].Save
[8].Set Firewall
[9].Restart Shutdown-Agent Service
Please Enter Your Choice => 8
We'll help to insert or remove the firewall rules of ShutdownAgent for you,
you'll need to save and restore the firewall rules by yourselves if it works.
Do you want to insert or remove the firewall? [I]nsert, [R]emove
Please Enter Your Choice => _
```

8.2 Install VMware Tools for Guest OS

To shutdown the guest OS from ESXi5 server, you have to install the VMware tools for all of them so as to inform the guest OSes shutdown smoothly.


For Windows operating system.

Select the following menu Guest → Install/Upgrade VMware Tools

8.3 Configure ShutdownAgent for ESXi5


Please estimate the period of time during shutdown all of the guest operating systems which run in the ESXi5 server. Then

- 1. Login to the web interface of ShutdownAgent and the account level should greater than or equal to device manager.
- 2. Goto the Device → Host → Configure web page and fill the estimated time in the Run Before Shutdown field of the Reaction group.




user ivianuai-Page 35 -

3. We have built the **command.ESX5** script file for ESXi 5 to shutdown the guest OSes, please make sure the file name in the Execute Command File field is **command.ESX5** then check the Execute Command File checkbox to enable shutdown the guest OSes and ESXi5 server.




4. Press Submit button to update your changes.



8.4 Modify the Command. ESX5

It is required for the customer to modify the command. ESX5 script to provide the user name, password for the vMA to communicate with the ESXi5 server.

Please login to the vMA server, open the following script file by a text edit with the root privilege: /usr/local/upsagent/command/command.ESX5.



USERNAME: The root account of the ESXi5 server.

PASSWORD: The password for the root account of the ESXi5 server.

SERVERIP: The IP address of the ESXi5 server.

LOCALIP: The IP address of the vMA server.

Normally you have to provide the root password for the PASSWORD and the ESXi5 server ip address for the SERVERIP. The script gets the vMA IP address from the eth0 interface automatically, if it is incorrect with your network configuration please change it to the interface which you have created.

9. XenServer Setup for ShutdownAgent

To install the ShutdownAgent in theCitrix XenServer, please see 2.2 For Linux in chapter 2 Installation/ Uninstallation.

To configure the basic networking parameters including the Xen firewall, please see chapter 3 Console Configuration.


9.1 Install PV driver for Guest OS

To shutdown the guest OS from XenServer, you need to install the PV driver for all of them so as to inform the guest OSes shutdown smoothly.


9.2 Configure UPSentry Cloud for Xen

The only thing that you need to do is to estimate the period of time during shutdown all of the guest operating systems which run in the XenServer. Then

- 1. Login to the web interface of ShutdownAgent and the account level should greater than or equal to device manager.
- 2. Goto the Device → Host → Configure web page and fill the estimated time in the Run Before Shutdown field of the Reaction group.



3. We have built the **command.Xen** script file to shutdown the guest OSes, so you have to change the file name from command.ESX to command.Xen in the Execute Command File. Please then check the Execute Command File checkbox to enable shutdown the guest OSes.



4. Press **Submit** button to update your changes.

10. Linux KVM Setup for ShutdownAgent

To install the ShutdownAgent in the Linux server, please see 2.2 For Linux in chapter 2 Installation/ Uninstallation.

To configure the basic networking parameters including the firewall, please see chapter 3 Console Configuration.

10.1 Install libvirt Tools for KVM


To shutdown the guest OS from Linux server, you have to install the libvirt. ShutdownAgent calls the virsh to shutdown the running guest OSes.

10.2 Configure ShutdownAgent for KVM


The only thing that you need to do is to estimate the period of time during shutdown all of the guest operating systems which run in the KVM server.

Then


- 1. Login to the web interface of ShutdownAgent and the account level should greater than or equal to device manager.
- Goto the Device → Host → Configure web page and fill the estimated time in the Run Before Shutdown field of the Reaction group.



3. We have built the **command.KVM** script file to shutdown the guest OSes, so you have to change the file name from command.ESX to command.KVM in the Execute Command File. Please then check the Execute Command File checkbox to enable shutdown the guest OSes.




4. Press Submit button to update your changes.




11. Work with the SNMP Card

11.1 Legacy Delta InsightPower SNMP Card

- 1. Open a web browser and connect to the InsightPower SNMP Card.
- 2. Record the IP address and SNMP Trap Port in the System Configuration web page.




3. Add the SNMP IP address and the trap port to the ShutdownAgent as the following to receive the SNMP trap from the InsightPower SNMP Card.



4. Get the ShutdownAgent ip address form the property dialog box.




5. Add the ShutdownAgent ip address to the SNMP Trap table in the InsightPower SNMP Card. Please select the "Information" for the Event Level and DeltaV4 as the Trap MIB Type.




11.2 New Delta InsightPower SNMP IPv6 Card


- 1. Open a web browser and connect to the InsightPower SNMP IPv6 Card.
- 2. Record the IP address in the System Configuration web page. The SNMP Trap is assigned in the SNMP Trap web page individually.




3. Login to the ShutdownAgent web and add the SNMP IP address and the trap port as the following to receive the SNMP trap from the SNMP Card.



4. Open the ShutdownAgent property from Windows task bar to get the IP address of the server.



5. Back to the InsightPower SNMP IPv6 card web page, add the IP address of ShutdownAgent to the SNMP Trap table. Please select the "ShutdownAgent 2012" for the Event Level and UPSV4 or UPSv5 as the Trap MIB.



6. If you enable the manageable option in the ShutdownAgent then you can observe all of the shutdown status, countdown timer and shutdown reason from the InsightPower SNMP IPv6 card. The web page is on the Monitor >> Information >> ShutdownAgent.

